

Primacrete ABS.

Primacrete ABS is an adhesion promoter for Luxury concrete® microcements when applied on non-absorbent substrates.



Characteristics

- Adhesion promoter for absorbent substrates.
- Can be applied by roller or brush in one coat application.
- Water-based, non flammable.
- Free of plasticisers, solvents, ammonia and emulsifiers.
- The product is supplied ready to use.

Technical data

- Water based acrylic dispersion
- Appearance: Milky liquid
- Solids: 10,7 %
- pH: Between 8 and 9
- Viscosity: 10-11s (Ford Cup 4)
- Density at 20°C: 1,01 ± 0,01 g/mL
- Application temperature: from 5°C to 35 °C
- Dry to touch: 30 minutes

Special precautions

In case of contact with eyes, rinse with plenty of water for 15 minutes.

In case of contact with skin wash with soap and water.

Do not swallow. If swallowed, do not induce vomiting and seek medical attention immediately.

The following measures are recommended:

- Good ventilation.
- Protective goggles to prevent splashing.
- Rubber gloves.

Empty containers should be disposed of in accordance with the legal regulations in force. To prevent the product from drying out or thickening, close the lid after each use. This product is non-toxic, non-hazardous and non-flammable under normal handling conditions. This product does not contain any harmful substances that would require, under current regulations, any additional labelling measures. Keep out of the reach of children.

Storage conditions

The product should be stored in its original closed packaging and protected from the weather at temperatures between 10°C and 30°C, in a dry and well-ventilated place, away from sources of heat and direct sunlight. The shelf life is 1 year from the date of manufacture, properly stored.

Consumption

Generally

- 0,10 L/m²

Application

The substrate must be dry, clean and firm, free of grease or oil. Wait a minimum of 30 minutes and no more than 24 hours before applying the first coat of microcement.

Packaging

It is available in 5L.

Cleaning of the tools

The tools should be cleaned with water and soap immediately after using.